

SE and SL, 9-30 kW

50/60 Hz, DIN, Generation A, all languages

Installation and operating instructions



QR98142266

Installation and operating instructions
(all available languages)
<http://net.grundfos.com/qr/i/98142266>

be
think
innovate

GRUNDFOS 

SE and SL, 9-30 kW

English (GB)	
Installation and operating instructions	5
Български (BG)	
Упътване за монтаж и експлоатация	32
Čeština (CZ)	
Montážní a provozní návod	63
Deutsch (DE)	
Montage- und Betriebsanleitung	90
Dansk (DK)	
Monterings- og driftsinstruktion	121
Eesti (EE)	
Paigaldus- ja kasutusjuhend	148
Español (ES)	
Instrucciones de instalación y funcionamiento	175
Suomi (FI)	
Asennus- ja käyttöohjeet	206
Français (FR)	
Notice d'installation et de fonctionnement	233
Ελληνικά (GR)	
Οδηγίες εγκατάστασης και λειτουργίας	262
Hrvatski (HR)	
Montažne i pogonske upute	293
Magyar (HU)	
Telepítési és üzemeltetési utasítás	320
Italiano (IT)	
Istruzioni di installazione e funzionamento	349
Lietuviškai (LT)	
Įrengimo ir naudojimo instrukcija	378
Latviešu (LV)	
Uzstādīšanas un ekspluatācijas instrukcija	405
Nederlands (NL)	
Installatie- en bedieningsinstructies	433
Polski (PL)	
Instrukcja montażu i eksploatacji	462

Português (PT)	
Instruções de instalação e funcionamento	492
Română (RO)	
Instrucțiuni de instalare și utilizare	521
Srpski (RS)	
Uputstvo za instalaciju i rad	550
Svenska (SE)	
Monterings- och driftsinstruktion	577
Slovenčina (SK)	
Návod na montáž a prevádzku	603
Türkçe (TR)	
Montaj ve kullanım kılavuzu	630
Українська (UA)	
Інструкції з монтажу та експлуатації	657
中文 (CN)	
安装和使用说明书	688
Norsk (NO)	
Installasjons- og driftsinstruksjoner	713
(AR) العربية	
تعليمات التركيب و التشغيل	740
繁體中文 (TW)	
安裝操作手冊	765
Appendix A	790

English (GB) Installation and operating instructions

Original installation and operating instructions

Table of contents

1.	General information	5
1.1	Hazard statements	5
1.2	Notes	5
1.3	Target group.	6
2.	Product introduction	6
2.1	Product description	6
2.2	Intended use	7
2.3	Pumped liquids	7
2.4	Identification.	7
2.5	Approvals	9
3.	Receiving the product.	11
3.1	Transporting the product	11
3.2	Inspecting the product	11
3.3	Lifting the product.	11
4.	Mechanical installation	13
4.1	Foundation	13
4.2	Mounting the product	14
4.3	Permanent, vertical, submerged installation on auto coupling	14
4.4	Permanent, vertical or horizontal, dry installation.	15
4.5	Temporary, vertical, submerged installation in a pit.	16
4.6	Level of pumped liquid	16
4.7	Torques for inlet and outlet flanges.	18
5.	Electrical connection	19
5.1	Frequency converter operation	20
5.2	Cable data.	20
5.3	Sensors	21
6.	Startup	23
7.	Storing the product	24
8.	Servicing and maintaining the product	24
8.1	Motor liquid check and change	25
8.2	Inspecting and adjusting the impeller clearance	26
8.3	Maintaining the explosion-proof SE, SL pumps	27
8.4	Contaminated pumps	28
9.	Troubleshooting	29
10.	Technical data	31
11.	Disposing of the product	31

1. General information



Read this document before you install the product. Installation and operation must comply with local regulations and accepted codes of good practice.

1.1 Hazard statements

The symbols and hazard statements below may appear in Grundfos installation and operating instructions, safety instructions and service instructions.



DANGER

Indicates a hazardous situation which, if not avoided, will result in death or serious personal injury.



WARNING

Indicates a hazardous situation which, if not avoided, could result in death or serious personal injury.



CAUTION

Indicates a hazardous situation which, if not avoided, could result in minor or moderate personal injury.

The hazard statements are structured in the following way:



SIGNAL WORD

Description of the hazard

Consequence of ignoring the warning

- Action to avoid the hazard.

1.2 Notes

The symbols and notes below may appear in Grundfos installation and operating instructions, safety instructions and service instructions.



Observe these instructions for explosion-proof products.



A blue or grey circle with a white graphical symbol indicates that an action must be taken.



A red or grey circle with a diagonal bar, possibly with a black graphical symbol, indicates that an action must not be taken or must be stopped.



If these instructions are not observed, it may result in malfunction or damage to the equipment.



Tips and advice that make the work easier.


1.3 Target group

These installation and operating instructions are intended for professional installers.

2. Product introduction

2.1 Product description

The 9-30 kW SE and SL pumps are a range of SuperVortex and S-tube® impeller pumps specifically designed for pumping sewage and wastewater in a wide range of municipal, private and industrial applications.



SE, SL pump

Pos.	Description
1	Inlet
2	Outlet
3	Power and control cable
4	Lifting bracket
5	Terminal box
6	Submersible motor
7	Pump

TMD2516

2.2 Intended use

These pumps are designed for pumping sewage and wastewater in a wide range of municipal, private and industrial applications.

2.3 Pumped liquids

The pumps are designed for pumping:


- raw sewage with short and long fibres and particles in municipal and industrial wastewater systems
- sludge with dry solids content up to 3 % for pumps with S-tube® impellers and up to 5 % for pumps with SuperVortex impellers
- surface water
- industrial wastewater with fibrous material
- domestic wastewater with toilet waste
- unscreened sewage in municipal pumping stations or inlet pumping stations in wastewater treatment plants
- raw water.

Depending on the application, the pumps can be used in submerged or dry, horizontal or vertical installations.

2.4 Identification

2.4.1 Nameplate

The pumps can be identified by the nameplate on the motor top cover.



TM002833

6	Pump type designation
7	Pump type designation (line 2)
8	Model number
9	Production code, year and week
10	Enclosure class
11	Maximum installation depth
12	Maximum head
13	Maximum flow rate
14	Number of phases
15	Maximum liquid temperature
16	Rated power input P1
17	Rated power output P2
18	Rated speed
19	Cos φ, 1/1-load
20	Rated voltage, delta connection
21	Rated current, delta connection
22	Rated voltage, star connection
23	Rated current, star connection
24	Frequency
25	Insulation class
26	Approvals
27	Weight

Nameplate example for Ex-proof pump

Pos.	Description
1	Approvals
2	Marking of explosion protection
3	Explosion protection certificate no.
4	Ex description
5	Ambient temperature

2.4.2 Type key

Example: SL1.110.200.245.4.52.M.S.EX.6.1G.A

Code	Explanation	Designation	
SE	Sewage pump with cooling jacket	Pump type	
SL	Sewage pump without cooling jacket		
[]	Open S-tube® impeller (semi-open)	Impeller type	
1	Closed single-channel S-tube® impeller		
2	Closed two-channel S-tube® impeller		
V	SuperVortex (free-flow) impeller		
110	Maximum solids size	Pump free passage [mm]	
200	Pump outlet nominal diameter	Pump outlet [mm]	
245	24.5 kW: P2 / 10	Power [kW]	
[]	Standard pump or standard Ex pump	Sensor version	
A	Sensor version 1 or sensor version 1, Ex pump		
B	Sensor version 2 or sensor version 2, Ex pump		
2	2-pole motor		Number of poles
4	4-pole motor		
6	6-pole motor		
52	Frame size of the pump	Frame size	
S	Super-high pressure	Pressure range	
H	High pressure		
M	Medium pressure		
L	Low pressure		
E	Extra-low pressure		

Code	Explanation	Designation
S	Sewage pump without cooling jacket for vertical, submerged installation (SL)	Installation type
C	Sewage pump with cooling jacket for vertical, submerged installation (SE)	
D	Sewage pump with cooling jacket for vertical, dry installation (SE)	
H	Sewage pump with cooling jacket for horizontal, dry installation (SE)	
[]	Cast iron pump housing, cast iron impeller, cast iron suction cover, cast iron motor housing	Material code for pump housing, impeller, suction cover and motor housing
Q	Cast iron pump housing, stainless-steel impeller, cast iron suction cover, cast iron motor housing	
W	Cast iron pump housing, heavy-duty wear-resistant impeller and suction cover, cast iron motor housing	
N	Pump without ATEX approval	Pump version
EX	Pump with ATEX approval	
5	50 Hz	Frequency
6	60 Hz	
1D	3 × 380-415D, 660-690Y (Standard)	Voltage for 50 Hz
1E	3 × 220-240D, 380-415Y	
1N	3 × 500-550D	
1F	3 × 220-277D, 380-480Y	Voltage for 60 Hz
1G*	3 × 380-480D, 660-690Y (Standard)	
1M	3 × 500-600D	
11**	3 × 460D (Standard)	
15**	3 × 380D, 660Y	

Code	Explanation	Designation
[]	Thermal switches	Thermal protection
T	PTC thermistor	
[]	1st generation	Generation code
A	2nd generation	
Z	Custom-built products	Customisation

*Only for 2- and 4-pole motors.

**Only for 6-pole motors.

2.5 Approvals

The explosion-proof versions have been approved by FM Approvals according to the ATEX directive and IEC standards.

2.5.1 Explanation of Ex approval

The SE, SL 9-30 kW pumps have the following explosion protection classification:

ATEX

Direct-drive pump:	CE 0344 Ⓜ II 2 G Ex h db IIB T4 Gb IP68
Pump driven by frequency converter:	CE 0344 Ⓜ II 2 G Ex h db IIB T3 Gb IP68

ICEX

Direct-drive pump:	Ex db IIB T4 Gb Ta = -20 to +40 °C
Pump driven by frequency converter:	Ex db IIB T3 Gb Ta = -20 to +40 °C

IEC 60079-0:2017, IEC 60079-1:2014

Directive or standard	Code	Description
ATEX	CE 0344	= CE marking of conformity according to the ATEX directive 2014/34/EU, Annex X. 0344 is the number of the notified body which has certified the quality system for ATEX.
	Ⓜ	= The equipment conforms to the harmonised European standard.
	II	= Equipment group according to the ATEX directive, defining the requirements applicable to the equipment in this group.
	2	= Equipment category according to the ATEX directive, defining the requirements applicable to the equipment in this category.
	G	= Explosive atmospheres caused by gases, vapours or mists.

Directive or standard	Code	Description
Harmonised European EN and IECEx standards	Ex	= Marking of explosion protection.
	db	= Flame proof enclosure according to EN/IEC 60079-1.
	h	= Non-electrical equipment for explosive atmosphere.
	II	= Suitable for use in explosive atmospheres (not mines).
	B	= Classification of gases, see EN/IEC 60079-0, Annex A. Gas group B includes gas group A.
	T4, T3*	T3* = maximum surface temperature of the motor is 200 °C according to EN/IEC 60079-0. T4 = maximum surface temperature of the motor is 135 °C according to EN/IEC 60079-0.
	Gb	= Equipment for explosive gas with "high" level of protection.
	IP68	= Enclosure class according to EN/IEC 60529.
X	The letter X in the certificate number indicates that the equipment is subject to special conditions for safe use. The conditions are described in the certificate and the installation and operating instructions.	

*When operated by a frequency converter.

2.5.2 Ex certification and classification

Explosion-proof pumps are approved by FM Approvals in conformity with the essential health and safety requirements relating to the design and construction of equipment intended for use in potentially explosive atmospheres given in Annex II to the Council Directive 2014/34/EU (ATEX).

2.5.3 Potentially explosive environments

Use explosion-proof pumps for applications in potentially explosive environments.



The pump must not be used to pump explosive, flammable or combustible liquids.



The classification of the installation site must comply with the local regulations.



Special conditions for safe use of explosion-proof pumps:

1. Make sure the moisture- and thermal switches are connected in two separate circuits and have separate alarm outputs (motor stop) in case of high humidity or high temperature in the motor.
2. Bolts used for replacement must be class A4-80 or A2-80 according to EN/ISO 3506-1.
3. Contact the manufacturer if dimensional information on the flameproof joints is necessary.
4. During operation, the cooling jacket, if fitted, must be filled with cooling liquid.
5. The level of the pumped liquid must be controlled by level switches connected to the motor control circuit.
6. Dry running is not allowed.
7. Make sure the cable is mechanically protected, attached to the switchboard and the cable bonding cannot slip out.
8. The sewage pumps have an ambient temperature range of -20 to +40 °C and a maximum operating temperature of +40 °C.
9. Avoid exposing the ethylene-propylene rubber insulated cables to direct sunlight.
10. Dry-installed pumps often have a higher temperature in the cable entries than submerged pumps. This may reduce the lifetime of the Ex-protection. According to IEC/EN 60079-14, it is a

user responsibility to regularly inspect the condition of the permanently attached cables and cable entries for any visual damage, cracks or embrittlement caused by rubber aging.

11. The thermal protector in the stator windings must have a rated switch temperature of 150 °C and it ensures the disconnection of the power supply. Resetting must be carried out manually.
12. To avoid electrostatic discharge, clean the cables and the painted parts of the pump with a wet fabric.
13. When the pump is operated by a frequency converter, the installation must be rated up to T3 temperature class. When the pump is operated without a frequency converter, the installation must be rated up to T4 temperature class.
14. This EC type examination certificate is only for II 2G Ex db IIB T4, T3, Gb, Ta = -20 to +40 °C, IP68. It does not cover concept h. Concept h is manufacturer self-declaration. The manufacturer has sent to FM Approvals a copy of his assessment for concept h. This has not been reviewed and is not endorsed by FM Approvals. It is held on file for completeness only.

3. Receiving the product

The pump is supplied from the factory in a proper packaging in which it should remain until installation. Make sure that the pump cannot roll or fall over.

3.1 Transporting the product

All lifting equipment must be rated for the purpose and checked for damage before lifting the pump. The lifting equipment rating must not be exceeded. The pump weight is stated on the nameplate.

CAUTION

Crushing hazard

Minor or moderate personal injury

- Make sure the pump cannot roll or fall over.

WARNING

Crushing hazard

Death or serious personal injury

- Use a service stand to support DN 100 and DN 150 (pressure ranges S and H) in vertical position.

WARNING

Crushing hazard

Death or serious personal injury

- Always lift the pump by its lifting bracket or use a forklift.

DANGER

Electric shock

Death or serious personal injury

- Never lift the pump by the power cable, hose or pipe.

Leave the cable-end protectors and control cables on the power supply until making the electrical connection. Whether insulated or not, the free cable end must never be exposed to moisture.

3.2 Inspecting the product

During periods of storage, protect the pump against moisture and heat.

Transportation and storage temperature:

-20 to +60 °C.

If the pump is not in operation or is being stored for more than a month, turn the impeller once a month.

WARNING

Crushing hazard

Death or serious personal injury

- Do not turn the impeller by hand. Always use an appropriate tool.

On pumps fitted with guide vane, be careful not to damage the guide vane when turning the impeller.

After a period of storage, inspect the pump before putting it into operation. Make sure that the impeller can rotate freely. Pay attention to the condition of the shaft seals, O-rings and the cable entries.

3.3 Lifting the product

DANGER

Crushing hazard

Death or serious personal injury

- Make sure the lifting bracket or lifting eye bolts are tightened before lifting the pump. Torque: 70 ± 4 Nm

**DANGER****Crushing hazard**

Death or serious personal injury

- Pumps with installation type S, C and pressure range S, H are delivered with a mounted lifting eye and an additional shackle, which must be used to attach the hook and the chain correctly.



When lifting the pump, use the right lifting point to keep the pump balanced for proper installation. The table below shows the correct lifting point.

Installation type	Pressure range	Lifting bracket assembly	Lifting point
S, C	S, H	with lifting eye and shackle	Pos. 2, see fig. Lifting points, vertical installation
	M, L, E	no lifting eye	Pos. 1, see fig. Lifting points, vertical installation
D	S, H, M, L, E	no lifting eye	Pos. 1, see fig. Lifting points, vertical installation
H	S, H, M, L, E	no lifting eye	See fig. Lifting points, horizontal installation

The following installation types must be lifted at the lifting bracket:

- types S with pressure range M, L and E
- types C with pressure range M, L and E
- type D.


See fig. Lifting points, vertical installation, pos. 1.

The following installation types must be lifted at the lifting eye with shackle (at the back of the lifting bracket):


- types S with pressure range S and H
- types C with pressure range S and H.

See fig. Lifting points, vertical installation, pos. 2.

Installation type H can be lifted by a hole in the flange and the middle lifting point. See fig. Lifting points, horizontal installation.



Lifting points, vertical installation



Lifting points, horizontal installation

TM075 007

TM075 008

4. Mechanical installation

Fit the extra nameplate supplied with the pump at the installation site.

Observe all safety regulations at the installation site. Make sure there is adequate fresh air supply in the pit.

DANGER

Electric shock

Death or serious personal injury



- Before starting any work on the product, make sure that the power supply is switched off and it cannot be switched on unintentionally.

DANGER

Crushing hazard

Death or serious personal injury



- During installation, always support the pump by lifting chains or place it in horizontal position to secure stability.

CAUTION

Crushing hazard

Minor or moderate personal injury



- Do not put your hands or any tool into the pump inlet or outlet after the pump has been connected to the power supply, unless the main switch has been locked in position 0.
- Make sure that the power supply cannot be switched on unintentionally.



The free end of the cable must not be submerged as water may penetrate into the motor.




Make sure that the pipes are installed without the use of undue force. No loads from the weight of the pipes must be carried by the pump. Use loose flanges to ease the installation and to avoid pipe tension at the flanges.

- The mass of the concrete foundation must be minimum 3-5 times heavier than the weight of the supported equipment and must have sufficient rigidity to withstand the axial, transverse, and torsional loads generated by the pump.
- The foundation must be 15 cm wider than the baseplate for pumps up to 350 kW and 25 cm wider for larger pumps.
- The concrete used in the foundation must have a minimum tensile strength of 250 N/cm².
- Always use epoxy grout to fasten the baseplate to the foundation.




Pumps with DN 250 or DN 300 flanges must be installed on a concrete foundation.

Dry, vertical installation on vertical base stand (left) and on concrete foundation (right)



TM029110



TM029111

4.1 Foundation

Foundations for pumps above 15 kW

The rotating equipment generates vibrations when an impeller or rotor is turning at high speed. Proper installation and anchorage of the pumps and accessories are crucial to limit vibrations and achieve reliable installation:

- The foundation and concrete must support the weight of the pump including accessories, the liquid passing through the pump and the forces generated by the pump.

4.2 Mounting the product

Installation type	Description	Installation and accessories
S	Sewage pump without cooling jacket for vertical, submerged installation	Permanent installation on auto coupling
		Temporary installation on ring stand
C	Sewage pump with cooling jacket for vertical, submerged installation	Permanent installation on auto coupling
		Temporary installation on ring stand
D	Sewage pump with cooling jacket for vertical, dry installation	Permanent installation on base stand
		Permanent installation on baseplate
H	Sewage pump with cooling jacket for horizontal, dry installation	Permanent installation on base stand for horizontal installation

4.3 Permanent, vertical, submerged installation on auto coupling

Pumps for permanent, vertical installation in a pit can be installed on a stationary auto-coupling unit and operated completely or partially submerged in the pumped liquid.



Make sure that the pipes are installed without the use of undue force. No loads from the weight of the pipes must be carried by the pump. Use loose flanges to ease the installation and to avoid pipe tension at the flanges.



Do not use elastic elements or bellows to connect the pipes.



In some installations, a plinth is required beneath the auto coupling to ensure correct installation of the pump. Consider this during the design of the installation.




The guide rails must not have any axial play as this may cause noise during operation.

Proceed as follows:


1. Drill mounting holes for the guide-rail bracket on the inside of the pit and fasten it provisionally with two screws.
2. Place the auto-coupling base unit on the bottom of the pit. If the bottom is uneven, the auto-coupling base unit must be supported. Use a plumb line to establish the correct positioning. Fasten the auto coupling with expansion bolts.
3. Connect the outlet pipe in accordance with the generally accepted procedures. Avoid exposing the pipe to distortion or tension.
4. Place the guide rails on the auto-coupling base unit and adjust the length of the rails to the guide-rail bracket at the top of the pit.
5. Unscrew the provisionally fastened guide-rail bracket. Insert the expansion dowels into the holes. Fasten the guide-rail bracket on the inside of the pit. Tighten the bolts in the expansion dowels.
6. Clean out debris before lowering the pump into the pit.
7. Fit the guide shoe to the pump.
8. Slide the guide shoe along the guide-rails and lower the pump into the pit by a chain secured to the lifting bracket (fig. Lowering the pump along the guide rails). When the pump reaches the auto-coupling base unit, pull the lifting chain towards the guide rail several times to shake off any foreign substances (fig. Connecting the pump to auto coupling). When the chain is unstrained, the pump connects automatically to the auto-coupling unit (fig. Submerged installation on auto coupling).
9. Hang up the end of the chain on a suitable hook at the top of the pit. Make sure that the chain is straight but not strained.
10. Adjust the length of the power cable by coiling it up on a relief fitting to ensure that the cable is not damaged during operation. Fasten the relief fitting to a suitable hook at the top of the pit. Make sure that the cables are not sharply bent or pinched.
11. Connect the power- and the control cables, if any.




The free end of the cable must not be submerged as water may penetrate into the motor.



Lowering the pump along the guide rails



Connecting the pump to auto coupling



Submerged installation on auto coupling

TM075949

Pull-out strength for anchor bolts

Auto-coupling base unit	Bolts [mm]	Pull-out strength for a single bolt [kN]
DN 80/100	M16	10
DN 100	M16	10
DN 150	M16	10
DN 200	M24	10
DN 250	M24	10
DN 300	M24	12




The pull-out strengths stated are without safety factor. The required safety factor may depend on the materials and method used for anchoring.

4.4 Permanent, vertical or horizontal, dry installation



Use isolating valves on either side of the pump to facilitate service on it.

TM075952



Dry, horizontal installation on horizontal base stand

Pumps in dry installation are installed permanently in a pump room.

The pump motor is enclosed and watertight.

Proceed as follows:

1. Mark and drill mounting holes in the concrete floor or foundation.
2. Fit the bracket or base stand to the pump.
3. Fasten the pump with expansion bolts.
4. Check that the pump is vertical or horizontal.
5. Fit the inlet and outlet pipes and isolating valves, if used, and ensure that the pump is not stressed by the pipes.
6. Adjust the length of the power cable by coiling it up on a relief fitting to ensure that the cable is not damaged during operation. Fasten the relief fitting to a suitable hook. Make sure that the cables are not sharply bent or pinched.
7. Connect the power- and the control cables, if any.

Fasten the pump to the inlet and outlet pipes with flange connections.


Pull-out strength for anchor bolts

Installation types D and H	Bolts	Pull-out strength for a single bolt [kN]
-	-	5.0



The pull-out strengths stated are without safety factor. The required safety factor may depend on the materials and method used for anchoring.

In horizontal installations, use a reducer between the inlet pipe and the pump. The reducer must be eccentric and has to be installed the way its straight edge is pointing upwards. Therefore the accumulation of air in the inlet pipe and the risk of operation disturbance are eliminated.



Eccentric reducer in horizontal installation

Pos	Description
1	Eccentric reducer
2	Minimum level: 0.2 m

4.5 Temporary, vertical, submerged installation in a pit



Use the chain to move the pump.

Proceed as follows:

1. Fit the ring stand to the pump inlet flange.
2. Fit a 90 ° elbow to the pump outlet and connect the outlet pipe or hose. If a hose is used, make sure that the hose does not buckle and the inside diameter matches the outlet diameter.
3. Lower the pump into the liquid by a chain secured to the lifting bracket of the pump. Place the pump on a level, solid foundation.
4. When the pump is placed firmly on the bottom of the pit, attach the end of the chain to a suitable hook at the top of the pit, so the chain cannot come into contact with the pump housing.
5. Adjust the length of the power cable by coiling it up on a relief fitting to ensure that the cable is not damaged during operation. Fasten the relief fitting to a suitable hook. Make sure that the cables are not sharply bent or pinched.
6. Connect the power and control cables, if any.

4.6 Level of pumped liquid

Do not let the pump run dry.

Install an additional level switch to ensure that the pump is stopped in case the stop level switch is not working.

The level of the pumped liquid must be controlled by level switches connected to the motor control circuit.



Explosion-proof SL pumps (without cooling jacket), installation type S, must always be completely submerged in the pumped liquid to the top of the motor. See fig. Liquid levels, level 1.




For explosion-proof SE pumps (with cooling jacket), installation type C, the pump housing must always be completely covered by the pumped liquid. See fig. Liquid levels, level 2.



For a short period, the pump may be used to pump down the liquid level to remove the float layer. For explosion-proof pumps, do not let it go below the stop levels shown in fig. Liquid levels.

To ensure adequate motor cooling, the following minimum requirements must be met:

- **Installation type S:** the pump must be completely submerged in the pumped liquid to the top of the motor. See fig. Liquid levels, level 1.
- **Installation type C:** the pump housing must be completely covered by the pumped liquid. See fig. Liquid levels, level 2.



TMB/0115

Liquid levels

- **Installation types D and H:** there are no special requirements for the level of the pumped liquid.

4.7 Torques for inlet and outlet flanges

Grade 4.6 (5) galvanised steel bolts and nuts

	Nominal diameter	Pitch circle diameter [mm]	Bolts [mm]	Torques [Nm]	
				Slightly oiled	Well lubricated
Inlet	DN 65	145	4 x M16	70	60
	DN 80	160	8 x M16	70	60
	DN 100	180	8 x M16	70	60
	DN 150	240	8 x M20	140	120
Outlet	DN 65	145	4 x M16	70	60
	DN 80	160	8 x M16	70	60
	DN 100	180	8 x M16	70	60
	DN 150	240	8 x M20	120	100

Specified tightening torques rounded off by ± 5 Nm

Grade A2.50 (AISI 304) steel bolts and nuts

	Nominal diameter	Pitch circle diameter [mm]	Bolts [mm]	Torques [Nm]	
				Slightly oiled	Well lubricated
Inlet	DN 65	145	4 x M16	-	60
	DN 80	160	8 x M16	-	60
	DN 100	180	8 x M16	-	60
	DN 150	240	8 x M20	-	120
Outlet	DN 65	145	4 x M16	-	60
	DN 80	160	8 x M16	-	60
	DN 100	180	8 x M16	-	60
	DN 150	240	8 x M20	-	100

Specified tightening torques rounded off by ± 5 Nm



The gasket must be a full-face, reinforced paper gasket, such as Klingersil C4300. When using a softer gasket material, reconsider the torques.

5. Electrical connection

DANGER

Electric shock

Death or serious personal injury



- Before starting any work on the product, make sure that the power supply is switched off and that it cannot be switched on unintentionally.

DANGER

Electric shock

Death or serious personal injury



- The pump must be grounded. Before connecting the pump to the voltage supply, make sure the connection to ground complies with the local regulations.

Connect the pump to an external main switch ensuring all-pole disconnection with a contact separation according to EN 60204-1, 5.3.2. It must be possible to lock the main switch in position 0.



The supply voltage and frequency are marked on the nameplate. Make sure that the motor is suitable for the power supply at the installation site.

The electrical connection must comply with the local regulations.



Connect the pumps to a controller with a motor protection relay with IEC trip class 10 or 15 or NEMA-equivalent.



The power supply for the motor protection circuit must be low voltage, class 2.



Connect pumps installed in hazardous locations to a control box with a motor protection relay with an IEC trip class 10.

1. Do not install pump controllers, Ex barriers or the free end of the power cable in potentially explosive environments.
2. The classification of the installation site must comply with the local rules.
3. On explosion-proof pumps, make sure that an external ground conductor is connected to the external ground terminal on the pump by a secure cable clamp. Clean the surface of the external ground connection and mount the cable clamp.
4. The ground conductor must be minimum AWG 12 type RHH, RHW, RHW-2 or similar, rated for 600 V and minimum 90 °C, yellow and green.
5. Make sure that the ground conductor is protected from corrosion.
6. Make sure that all protective equipment has been connected correctly.
7. Float switches used in potentially explosive environments must be approved for this application. They must be connected to the Grundfos Dedicated Controls, DC, DCD or the SLC, DLC controllers, by an intrinsically safe barrier to ensure a safe circuit.



If the power cable is damaged, it must be replaced by the manufacturer or his service agent.

Connect the pump to a motor-protective circuit breaker.



Set the motor-protective circuit breaker to the rated current of the pump +15 % service factor. The rated current is stated on the nameplate.

The supply voltage and frequency are marked on the nameplate.

The voltage tolerance at the motor terminals must be within $\pm 10\%$ of the rated voltage.

The motor is effectively grounded with the power cable and pipes. The motor top cover is equipped with connections for external grounding or an equipotential bonding conductor.



Maintenance and service work on explosion-proof pumps must be carried out by Grundfos or an authorised service workshop.



Before installation and the first startup of the pump, check the condition of the cable to avoid short circuits.

The most commonly used startup methods are the following:

- Direct-on-line starting (DOL). See Appendix, fig. 4.3.
- Star-delta starting (Y/D). See Appendix, fig. 4.3.
- Soft start.

The selection of suitable starting method depends on several considerations on usage and mains supply conditions.



When using star-delta start, it is important to keep switching transient time to a minimum to avoid high transient torques. Use a time relay with a switching time of maximum 50 ms or according to the manufacturer's specifications.

The pump can be operated with a frequency converter according to the specifications of the manufacturer.

5.1 Frequency converter operation



If the motor is operated by a frequency converter, the temperature class of the explosion-proof pumps must be T3.

In principle, all three-phase motors can be connected to a frequency converter.

However, frequency converter operation often exposes the motor insulation system to a heavier load and may cause the motor to be more noisy due to eddy currents caused by voltage peaks.

In addition, large motors driven with a frequency converter are loaded by bearing currents.

For frequency converter operation, observe the following:

- The thermal protection of the motor must be connected.
- Peak voltage and dU/dt must be in accordance with the table below. The values stated are maximum values supplied to the motor terminals. The cable influence is not taken into account. See the frequency converter data sheet regarding the actual values and the cable influence on the peak voltage and dU/dt.
- The minimum switching frequency is 2 KHz. The switching frequency can be variable.
- If the pump is an Ex-approved pump, check if the Ex certificate of the specific pump allows the use of a frequency converter.
- Set the frequency converter U/f ratio according to the motor data.

- Before installing a frequency converter, calculate the lowest frequency allowed in the installation to avoid zero flow.
- Do not reduce the motor speed to less than 50 %.
- Keep the flow rate above 1 m/sec.
- Let the pump run at rated speed at least once a day to prevent sedimentation in the pipe network.
- Do not exceed the frequency indicated on the nameplate as this may cause motor overload.
- Keep the power cable as short as possible. The peak voltage increases with the length of the power cable.
- Use input and output filters on the frequency converter.
- Use a screened power cable if there is a risk that electrical noise may disturb other electrical equipment.
- Set the frequency converter for constant-torque operation. Pulse width modulation should be used.

When operating the pump by a frequency converter, consider the following:

- The locked-rotor torque can be lower depending on the type of the frequency converter.
- The noise level may increase. See the installation and operating instructions for the selected frequency converter.

Maximum repetitive peak voltage [V]	Maximum dU/dt U _N 400 V [V/μ sec.]
850	2000



Frequency converter use may reduce the lifespan of the bearings and the shaft seal, depending on the operating mode and other circumstances.

For more information about the frequency converter operation, see the data sheet and the installation and operating instructions for the selected frequency converter.

5.2 Cable data

Standard H07RN-F

Cable type [mm ²]	Outer cable diameter [mm]		Minimum bending radius [mm]
	min.	max.	
7 x 4 + 5 x 1.5	21.2	22.8	70
7 x 6 + 5 x 1.5	24.5	26.1	80
7 x 10 + 5 x 1.5	25.2	26.8	110

Electromagnetic Compatibility (EMC)

Cable type [mm ²]	Outer cable diameter [mm]		Minimum bending radius [mm]
	min.	max.	
3 x 6 + 4 x 2.5 + 5 x 0.5	26.3	28.3	90
3 x 10 + 4 x 2.5 + 5 x 0.5	26.3	28.3	120
3 x 16 + 4 x 4 + 5 x 0.5	26.3	28.3	140



The minimum size of the ground conductor must be equal to or bigger than the phase conductor.



The top cover of the explosion-proof pumps is provided with an external ground terminal to ensure the connection to the ground. The electrical installation must include an external connection from this terminal to the ground. The ground conductor must comply with all electrical safety regulations in force.



Before installation and the first startup of the pump, check the condition of the cable to avoid short circuits.

5.3 Sensors

The pumps can be equipped with various switches and sensors for protection. The specification table below indicates which switch and sensor types can be used.

For the wiring diagrams of the various switch and sensor types, see section Appendix.

Switch and sensor specification

	Standard pump	Sensor version 1	Sensor version 2	Standard Ex	Sensor, version 1 Ex	Sensor, version 2 Ex
Thermal switches or PTC	•	•	•	•	•	•
Moisture switch	•	•	•	•	•	•
Leakage switch in leakage chamber for standard motors	•	•	•			
Leakage switch in stator housing, for Ex motors				•	•	•

Pt1000 in stator winding	•	•	•	•
Pt1000 in upper bearing	•			•
Pt1000 in lower bearing	•			•
PVS3 vibration sensor	•			•
SM 113 module ¹		• ¹		• ¹
IO 113 module ²		• ²		• ²

¹ For pumps fitted with two power supply cables, the SM 113 module must be ordered separately and installed in the control cabinet. SM113 needs to be fitted with a resistor.

² The IO 113 with communication functionality has to be chosen and ordered separately.

5.3.1 Thermal switches

Three Klixon bimetallic thermal switches are built into the stator windings. A contact opens in case of overtemperature (150 °C). The motor insulation class is class H (180 °C).

The supply voltage to the thermal switches must be 12-24 V DC.

The thermal switches are connected to the control cable and must be connected to the safety circuit of the separate pump controller.

Check whether the circuit resistance is maximum 3 Ω per thermal switch, with a multimeter.



The motor-protective circuit breaker of the pump controller must include a circuit which automatically disconnects the power supply in case the protective circuit is opened.



In case the thermal switches or the moisture switches are not working, install an automatic circuit breaker.

5.3.2 Moisture switches and leakage switches

Non-Ex version:

One moisture switch and one leakage switch are mounted in a non-Ex pump. The moisture switch is placed in the top cover and the leakage switch is in the chamber above the shaft seal. See Appendix, fig. 4.3, section C-C and E-E.

Ex version:

One moisture switch and one leakage switch are mounted in an Ex pump. The moisture switch is placed in the top cover and the leakage switch is in the stator housing. See Appendix, fig. 4.3, section C-C and D-D.

All switches in both non-Ex and Ex versions are hardwired from the pump to IO 113. If moisture or a leakage is detected, they break an electric circuit. This generates both a hardware and a software alarm in IO 113, and the alarm relay opens.

Moisture and leakage switches are motor protection devices, which protect the motor from damage due to moisture or leakage. The switches are non-reversing and they must be replaced after they have been released.

The moisture and leakage switches are connected in a separate circuit and to the control cable. See Appendix. They are also to be connected to the safety circuit of the separate pump controller.

5.3.3 Thermistors

PTC thermistors are available as accessories or Factory Product Variants (FPV).

The thermistors can be used as motor protection devices to monitor stator temperature instead of thermal switches and must be connected to the thermistor relay in the control cabinet.

The operating voltage of PTC thermistors is 2.5 - 7.5 V.

Checks after electrical connection

1. Check whether the circuit resistance is below 150 Ω per thermistor, with a multimeter.
2. Check whether the insulation between circuit and stator housing is outside the range, with a multimeter.
3. Carry out similar measurements at the end of the power cable.

Pt1000 temperature sensor

The Pt1000 temperature sensor is available as an accessory or an FPV.

The Pt1000 sensor is primarily used for the monitoring of bearing temperature, but it can also be used in the stator.

In case of overheating caused, the Pt1000 sensor trips an alarm and disconnects the power supply at a preset temperature.



The bearing temperature monitoring system is only available as an option.

The sensor resistance values are the following:

- 1000 Ω at 20 °C
- 1385 Ω at 100 °C
- approximately 1078 Ω at room temperature.

The temperature limits are the following:

- 90 °C: warning for bearing temperature
- 130 °C: pump stop caused by high bearing temperature
- 150 °C: pump stop caused by high stator temperature.



In Ex-approved pumps, the maximum acceptable alarm temperature in the bearing sensors is 100 °C for the lower bearing (shaft end) and 120 °C for the upper bearing.

Checks after electrical connection

1. Check whether the resistance at room temperature (20 °C) is approximately 1078 Ω, with a multimeter.
2. Check whether the insulation between the circuit and the stator housing is outside the range, with a multimeter.

- Carry out similar measurements at the end of the power cable.

During the pump check, the Pt1000 sensor must be connected to a recording device.

5.3.4 Pump vibration sensor (PVS 3)

The PVS 3 sensor monitors the vibration level to protect the pump and the pipe network against damage.

A change in the vibration level indicates an abnormal situation. Make sure that a service inspection is carried out before the pump or the pipe network is damaged.



Pumps are fitted with S-tube® impellers. The S-tube® impellers are wet-balanced to reduce vibrations during operation. If these pumps are started with the pump housing containing air, the vibration level can be higher than in normal operation.

SM 113

The SM 113 module is used for collecting and transferring sensor data. SM 113 works with IO 113 through power line communication using the Grundfos GENIbus protocol.

SM 113 collects data from the following devices:

- 3 current sensors, 4-20 mA
- 3 Pt1000 thermal sensors
- 1 PTC thermal sensor
- 1 digital input.



SM113 is fitted with a 2.7 kΩ resistor to avoid false sensor alarms in the IO113.

IO 113

The IO 113 module is the interface between a pump with analogue and digital sensors and the pump controller. The most important sensor data are indicated on the front panel.

One pump can be connected to IO 113.

With the sensors, IO 113 is a galvanic separation between the motor voltage in the pump and the connected controller.

IO 113 enables the following functions:

- overtemperature protection
- monitoring the sensors for analogue measurement of:
 - motor temperature
 - pump vibrations
 - stator insulation resistance
 - bearing temperature
 - moisture in motor
- stopping the pump in case of alarm

- monitoring remotely the pump through RS485 communication (Modbus or GENIbus).

Measurement of insulation resistance

IO 113 measures the insulation resistance between a stator winding and ground:

- resistance above 10 MΩ = OK
- resistance between 10 MΩ and 1 MΩ = warning
- resistance below 1 MΩ = alarm.

6. Startup



DANGER

Electric shock

Death or serious personal injury

- Make sure the pump is grounded.



Pumps in dry installation must be vented.



Before the first startup and after a long standstill period, make sure that the pump is filled with the pumped liquid.



Make sure that the pump is filled with the pumped liquid.

Dry-running is not allowed.



In case of abnormal noise or vibrations, stop the pump immediately. Do not restart the pump until the cause of the fault is identified and eliminated.

Proceed as follows:

1. Remove the fuses or switch off the main switch.
2. Check the motor liquid level in the cooling chamber. Checking the motor liquid
3. Check if the impeller can rotate freely.
4. Check if the switches are closed, replace if necessary.
5. Check whether the monitoring units, if used, are operating properly.
6. For pumps in a submerged installation, make sure that the pump is submerged in the liquid.
7. For pumps in dry installation, make sure that there is liquid in the pit.
8. Open the isolating valves, if fitted.
9. Check if the system is filled with liquid and vented.
10. Check the settings of the level switches.

11. Start the pump and check the operation for abnormal noise or vibrations.
12. After startup, the actual pump duty point must be established. Make sure the operating conditions are met.



The pump may only be started for a short period without being submerged for checking the direction of rotation.

Always operate the pump in accordance with established routines and perform scheduled checks of pump monitoring equipment and accessories. Make sure that the pump and equipment settings cannot be changed by unauthorised persons.

7. Storing the product

For periods of storage, the pump must be protected against moisture and heat.

After a period of storage, inspect the pump before putting it into operation. Make sure that the impeller can rotate freely. Pay attention to the condition of the shaft seals, O-rings and the cable entries.



Leave the cable-end protectors and control cables on the power until starting the electrical connection. Whether insulated or not, the free cable end must never be exposed to moisture. Non-compliance with this may cause damage to the motor.



If the pump is being stored for more than a month, turn the impeller at least every month to prevent the seal faces of the lower mechanical shaft seal from seizing up.

Avoiding this may cause damage to the shaft seal when the pump is started.

If the impeller cannot be turned, contact an authorised service workshop.

WARNING Crushing hazard

- Death or serious personal injury
- Do not turn the impeller by hand. Always use an appropriate tool.



On pumps fitted with guide vane, be careful not to damage the guide vane when turning the impeller.

8. Servicing and maintaining the product



Pumps with inlet flange DN 100 or DN 150 (pressure ranges S and H) in vertical position do not comply with the stability requirement of standard EN 809 (stable when tilted to an angle of 10 °). Use a service stand to support the pump.

Product numbers for service stand

Inlet flange size DN 100: 98669229.

Inlet flange size DN 150: 98669251.



WARNING Crushing hazard

Death or serious personal injury

- Always support the pump using lifting chains or place it in horizontal position to secure stability.



DANGER Electric shock

Death or serious personal injury

- Before starting any work on the product, make sure that the power supply is switched off and it cannot be switched on unintentionally.



DANGER Electric shock

Death or serious personal injury

- Make sure the pump is grounded.



The maintenance and service work on explosion-proof pumps must be carried out by Grundfos or an authorised service workshop.



Do not open the pump if the ambient atmosphere is explosive or dusty.



Maintenance and service must be carried out by qualified persons.

Before carrying out maintenance and service, make sure that the pump is thoroughly flushed with clean water. Rinse the pump parts after dismantling.

Pumps running normal operation must be inspected every 2000 operating hours or at least once a year. If the pumped liquid is muddy or sandy, the pump must be inspected every 1000 operating hours or every six months.



Frequency converter use may reduce the lifespan of the bearings and the shaft seal, depending on the operating mode and other circumstances.

Check the following:

- Power consumption
- Motor liquid level.

When the pump is new or after replacement of the shaft seals, check the motor liquid level and its water content after one week of operation. If the motor liquid level has dropped, the shaft seal may be defective.



Dispose of the motor liquid must comply with local regulations.

Number of poles	Quantity of motor liquid	
	SE [ltr]	SL [ltr]
2	12.8	4.5
4	12.8	4.5
6	14.1	5.4

- **Cable entries:** Make sure that the cable entries are waterproof and the cables are not sharply bent or pinched.
- **Impeller clearance:** Check the impeller clearance.
- **Pump parts:** Check the pump housing and other parts for possible wear. Replace defective parts.
- **Ball bearings:** Check the shaft for noisy or heavy operation (turn the shaft by hand). Replace defective ball bearings.
- **General maintenance:** It is usually required in case of defective ball bearings or poor motor function. This work must be carried out by an authorised service workshop.



Replace the ball bearings at least every 25.000 operating hours.

8.1 Motor liquid check and change



Clean the outside of the pump regularly to retain the heat conductivity.



Change the motor liquid once a year or after 2000 operating hours to prevent oxidation.



Lack of motor liquid may cause overheating and damage to the mechanical seals.



Use SML3 cooling liquid for motor cooling. Cooling liquids with lower specific heat capacity than SML3 may cause overheating to the motor.

8.1.1 Checking the motor liquid

The ingress level of the pumped liquid into the motor liquid can be checked. Use a refractometer (product no. 98676968) which shows the refractive index in percent. Always use the propylene glycol scale.

Measured freezing point	Liquid ingress percent (%)
-20 °C (-4 °F)	0
-18 °C (0.4 °F)	5
-17 °C (1.4 °F)	10
-15 °C (5 °F)	15
-14 °C (6.8 °F)	20

If the refractive index is higher than 20 %, change the motor liquid.

Do not exceed this level of refractive index to ensure the appropriate condition of the shaft seal and the bearings for reliable operation. For further information, see the service instruction for SE, SL pumps.

For draining and changing the motor liquid, see the SE/SL 9-30 kW Service instructions



0986248406

<http://net.grundfos.com/qr/i/98248406>



Drain the leakage chamber of the pump after 2000 operating hours.

WARNING**Pressurised system**

Death or serious personal injury

- The oil chamber may be under pressure. Loosen the screws carefully and do not remove them until the pressure has been fully relieved.



There must be minimum 10 % air in the seal housing due to thermal expansion of the motor liquid during operation.

8.2 Inspecting and adjusting the impeller clearance

For pumps with the closed S-tube[®] impeller, the impeller clearance is the distance between the bottom of the impeller and stationary wear ring.

For pumps fitted with the open S-tube[®], the impeller clearance is the distance between the bottom of the impeller and the suction cover.

The correct impeller clearance is required to maintain the pump's hydraulic performance and to prevent clogging.



Check the impeller clearance every time service is carried out to prevent hot surfaces in the hydraulic parts.

Clearance sizes for closed S-tube[®] impellers

Pressure range	Impeller clearance [mm]	Turning angle of set screw [degrees]
E = Extra-low pressure single-channel S-tube [®]	0.9 ± 0.1	170 °
E = Extra-low pressure two-channel S-tube [®]	0.7 ± 0.1	140 °
L = Low-pressure single-channel S-tube [®]	0.9 ± 0.1	170 °
L = Low-pressure two-channel S-tube [®]	0.7 ± 0.1	140 °
M = Medium pressure	0.6 ± 0.1	125 °
H = High pressure	0.6 ± 0.1	125 °
S = Super-high pressure	0.5 ± 0.1	110 °

Clearance sizes for open S-tube[®] impellers

Pressure range	Impeller clearance [mm]	Turning Angle of Set Screw (degrees)
H = High pressure	0.5 ± 0.1	110 °
S = Super-high pressure	0.5 ± 0.1	110 °

DANGER**Electric shock**

Death or serious personal injury

- Before starting any work on the product, make sure that the power supply is switched off and that it cannot be switched on unintentionally.



The impeller clearance of installation types S and C can be inspected directly through the pump inlet.




The impeller clearance of installation types D and H can be inspected and adjusted with the pump installed on the base stand and connected to the pipes.


8.2.1 Adjusting the impeller clearance



Tighten the fastening screws carefully to avoid damage to the bearings.
 The movement is usually 1 to 3 mm.



TM061916



TM07716


Impeller adjusting screws

1	Set screw
2	Fastening screw
3	Impeller clearance

The following method is suitable for pumps in vertical position. Proceed as follows:

- Loosen the fastening- and set screws so the impeller is sitting on the suction cover / stationary wear ring. When the impeller is in this position, the impeller clearance is zero.
- Tighten the three set screws down by hand until they touch the top surface of the volute.
- The impeller clearance is created by turning the set screws to a specified angle. Closed S-tube[®] and open S-tube[®] impellers, as well as the different head classes, have different impeller clearances. See the table above to determine the correct impeller clearance and turning angle.

- Once the correct angle is identified, turn the set screw clockwise by the specified angle. Use a turning gauge to ensure the set screw is tightened to the correct amount.
- Tighten the fastening screws in two steps, according to the sequence below:
 - Tighten the screws one by one, from 1 to 6. Required torque: 40 ± 4 Nm.
 - Repeat the previous sequence to the final torque of 70 ± 4 Nm



TM07792

Tightening sequence

8.3 Maintaining the explosion-proof SE, SL pumps

Overhauled and repaired explosion-proof pumps are marked with a repair plate providing the following information:

- repair symbol R
- name or registered trademark of the repairing workshop
- workshop reference number relating to the repair
- date of overhaul or repair.

In the event of subsequent repairs, the existing plate must be replaced by a new updated one and earlier markings must be recorded.

The repairing workshop must keep records of performed overhauls and repairs with records of all previous overhauls, repairs and possible modifications. Copies of the detailed records of the repairing workshop must be filed by the owner or operator with the original type certificate of the explosion-proof motor.

8.3.1 Power cable

Use manufacturer-approved and compatible cables that are suitable for the cable entry.

8.3.2 Cable entry

Use only Ex cable entry parts corresponding to the cable diameter. The correct cable dimension marking is stamped on the inlet or the cable entry.

8.3.3 Spare parts

Damaged motor parts must always be replaced by new and approved parts. Motor parts must not be reconditioned.

8.4 Contaminated pumps

The product is classified as contaminated, if it is used for contagious or toxic liquid.

CAUTION

Biological hazard

Minor or moderate personal injury



- Flush the pump thoroughly with clean water and rinse the pump parts after dismantling.

Before returning the product for service, contact Grundfos with details about the pumped liquid. Otherwise, Grundfos can deny to service the product.

9. Troubleshooting

DANGER

Electric shock

Death or serious personal injury

- Before starting any work on the product, make sure that the power supply is switched off and it cannot be switched on unintentionally.



DANGER

Electric shock

Death or serious personal injury

- The pump must be grounded.



Before diagnosing any fault, make sure that all rotating parts have stopped moving.



Observe all regulations applying to pumps installed in potentially explosive environments.

Make sure that no work is carried out in potentially explosive atmospheres.

Fault	Cause	Remedy	
The pump does not start or stops without visible cause.	No power supply.	Re-establish the power supply. Start the pump manually.	
	Missing phase.	Re-establish all phases.	
	The pump is overloaded.	If the fault does not disappear automatically, find the cause and remedy the fault.	
	The impeller is clogged by impurities.	Clean the impeller.	
	The motor-protective circuit breaker is set incorrectly.	Set the motor-protective circuit breaker according to the rated current.	
	The thermal switches are tripped. Insufficient motor cooling.	Re-establish the motor cooling.	
	The moisture switch in the motor is tripped.	Contact an authorised service workshop.	
	The power cable is defective.	Contact an authorised service workshop.	
The pump does not start or stops. The control panel indicates that the motor-protective circuit breaker or protection equipment is tripped.	The voltage is fluctuating.	Re-establish the correct voltage supply. Permissible deviation is $\pm 10\%$.	
	The direction of rotation is wrong.	Interchange two phases to the motor.	
	The impeller is loose or worn.	Tighten or replace the impeller.	
	The pump or the pipes are blocked by impurities.	Clean the pump or the pipes.	
	The pump runs, but does not deliver the rated flow.	The pump head is too high.	Measure the differential pressure and compare the value with the pump curve. Check that all valves are open or remove any blockage in the outlet pipe.
		The valves are closed or blocked. The non-return valve is not operating.	Clean or replace the valves.

Fault	Cause	Remedy
	There is air in the pump or the inlet pipe.	Vent the pump and the inlet pipe. Increase the stop level in the pit.
	The pumped liquid is too dense.	Dilute the pumped liquid.
	The pump is improperly connected to the auto coupling.	Pump down the liquid level in the pit. Lift out the pump and place it on the auto coupling again.
	There is leakage in the pipes.	Repair the pipes.
	The pit flushing system is inadvertently activated.	Check the function of the pit flushing system and repair it, if required.
The pump starts, but stops immediately.	The pump is clogged, which causes the motor-protective circuit breaker to trip.	Clean the pump.
	The motor is overheated, which causes the thermal switches to trip.	Allow the pump to cool. Clean the pump.
	The level switch is out of adjustment or defective.	Clean or set the level switch or replace them, if required.
The pump is vibrating or emitting excessive noise.	The pump is partly clogged by impurities.	Clean the pump.
	The direction of rotation is wrong.	Interchange two phases to the motor.
	The pump is operating outside the specified operating range.	Re-establish proper operating conditions.
	The pump is defective.	Repair the pump or contact an authorised workshop, if necessary.
	The pump is not properly connected to the auto coupling.	Pump down the liquid level in the pit. Lift out the pump and place the pump on the auto coupling.
	The pump is cavitating.	Clean the inlet pipe.
	The impeller is not in balance.	Contact an authorised service workshop.
	The base stand, the auto coupling, the ring stand or the guide rails are installed incorrectly.	Install the components correctly.
Low motor liquid level.	The upper mechanical shaft seal is leaking.	Contact an authorised service workshop.

10. Technical data

pH value

Pumps in permanent installations can cope with the following pH values:

Material variant	Installation	pH value
Standard ¹⁾	Dry and submerged	6-14 ³⁾
Q ²⁾	Dry and submerged	6-14 ³⁾

¹⁾ Cast iron impeller, pump housing and motor top.

²⁾ Stainless-steel impeller. Cast iron pump housing and motor top.

³⁾ For fluctuating pH values, the range is pH 4 to 14.

Flow rate

Keep a minimum flow rate to avoid sedimentation in the pipe network. Recommended flow rates:

- in vertical pipes: 0.7 m/s.
- in horizontal pipes: 1.0 m/s.

Ambient temperature



For explosion-proof pumps, the ambient temperature on the installation site must be in the range from -20 to +40 °C.

For non-explosion proof pumps, the ambient temperature may exceed +40 °C for a short period (maximum 3 minutes).

Liquid temperature

0 to +40 °C.

For non-explosion proof pumps, the liquid temperature may be up to 60 °C for a short period (maximum 3 minutes).



Explosion-proof pumps must never pump liquids of a temperature higher than +40 °C.

Operating mode

The pumps are designed for continuous operation.

Frequency of starts and stops

Maximum number of starts per hour is 20.

Installation depth

Maximum 20 m below liquid level.

Solids size

From 35 to 125 mm, depending on the pump size.

Enclosure class

IP68.

Sound Pressure



Use hearing protection when working nearby an installation in operation with a sound pressure level above 70 dB(A).

Motor liquid

The motor is factory-filled with Grundfos SML3 motor liquid which is frost-resistant until -20 °C. The motor liquid helps to transfer the heat generated by the motor to the cooling chamber and to the pumped liquid to pass on the outside of the pump.

Electrical data

The supply voltage and frequency are marked on the nameplate.

The voltage tolerance at the motor terminals must be within $\pm 10\%$ of the rated voltage.

11. Disposing of the product

This product or parts of it must be disposed of in an environmentally sound way.

1. Use the public or private waste collection service.
2. If this is not possible, contact the nearest Grundfos company or service workshop.



The crossed-out wheeled bin symbol on a product means that it must be disposed of separately from household waste. When a product marked with this symbol reaches its end of life, take it to a collection point designated by the local waste disposal authorities.

The separate collection and recycling of such products will help protect the environment and human health.


See also end-of-life information at

www.grundfos.com/product-recycling.

Appendix A

A.1. Wiring diagrams

A.1.1. Single cable, star-delta connection




12-wire, star-delta connections (Y/D): D: connections for 3 x 460 V (1G), 3 x 208 V (0S) or 3 x 230 V (1R) Y: connections for 3 x 460 V (1R)

A.1.2. Electromagnetic cable (EMC) single cable or double cable




Main supply voltage must be stated since the pump will be connected according to this from factory.



8-wire, EMC cable

TM1422884




TIM074220

18-wire / EMC double cable

A.2. Sensor wiring

A.2.1. Sensor wiring schematics for single cable pumps

A.2.1.1. Standard, single cable




TMA02087

Standard and Standard Ex, single cable

Pos.	Description
1	Thermal switches / Thermistor
2	Moisture / Leakage switch

A.2.1.2. Sensor version 1, single cable




TMA02090

Sensor version 1 and Sensor version 1 Ex, single cable

Pos.	Description
1	Thermal switches / Thermistor
2	Moisture / Leakage switch

A.2.1.3. Sensor version 2, single cable




TMA02092

Sensor version 2 and Sensor version 2 Ex, single cable

Pos.	Description
1	Thermal switches / Thermistor
2	Moisture / Leakage switch

A.2.2. Sensor wiring schematics for double cable pumps

A.2.2.1. Standard, double cable



P4

P5

P1

P2

P3


P4

P5

Standard and Standard Ex, double cable


Pos.	Description
1	Thermal switches / Thermistor
2	Moisture / Leakage switch

A.2.2.2. Sensor 1, double cable



P4

P5



P3

P4

P5


Sensor 1 and Sensor 1 Ex, double cable

Pos.	Description
1	Thermal switches / Thermistor
2	Moisture / Leakage switch
3	Pt1000 stator

TM074214

TM074218

A.2.2.3. Sensor 2, double cable




TMB74218

Sensor 2 and Sensor 2 Ex, double cable

Pos.	Description
1	Thermal switches / Thermistor
2	Moisture / Leakage switch
VIBRA	Vibration sensor
3	Pt1000 stator
4	Pt1000 upper bearing
5	Pt1000 lower bearing

A.2.3. Switch and sensor positions



Pos.	View	Description
1	C-C	Moisture switch
2	D-D	Leakage switch in stator housing, for Ex motors
3	E-E	Leakage switch in leakage chamber for standard motors

TM056242

Argentina

Bombas GRUNDFOS de Argentina S.A.
Ruta Panamericana km. 37.500/Industin
1619 - Garin Pcia. de B.A.
Tel.: +54-3327 414 444
Fax: +54-3327 45 3190

Australia

GRUNDFOS Pumps Pty. Ltd.
P.O. Box 2040
Regency Park
South Australia 5942
Tel.: +61-8-8461-4611
Fax: +61-8-8340-0155

Austria

GRUNDFOS Pumpen Vertrieb
Ges.m.b.H.
Grundfosstraße 2
A-5082 Grödig/Salzburg
Tel.: +43-6246-883-0
Fax: +43-6246-883-30

Belgium

N.V. GRUNDFOS Bellux S.A.
Boomssesteenweg 81-83
B-2630 Aartselaar
Tel.: +32-3-870 7300
Fax: +32-3-870 7301

Belarus

Представительство ГРУНДФОС в
Минске
220125, Минск
ул. Шафарнянская, 11, оф. 56, БЦ
«Порт»
Тел.: +375 17 397 397 3
+375 17 397 397 4
Факс: +375 17 397 397 1
E-mail: minsk@grundfos.com

Bosnia and Herzegovina

GRUNDFOS Sarajevo
Zmaja od Bosne 7-7A
BiH-71000 Sarajevo
Tel.: +387 33 592 480
Fax: +387 33 590 465
www.ba.grundfos.com
E-mail: grundfos@bih.net.ba

Brazil

BOMBAS GRUNDFOS DO BRASIL
Av. Humberto de Alencar Castelo
Branco, 630
CEP 09850 - 300
São Bernardo do Campo - SP
Tel.: +55-11 4393 5533
Fax: +55-11 4343 5015

Bulgaria

Grundfos Bulgaria EOOD
Slatina District
Iztocna Tangenta street no. 100
BG - 1592 Sofia
Tel.: +359 2 49 22 200
Fax: +359 2 49 22 201
E-mail: bulgaria@grundfos.bg

Canada

GRUNDFOS Canada inc.
2941 Brighton Road
Oakville, Ontario
L6H 6C9
Tel.: +1-905 829 9533
Fax: +1-905 829 9512

China

GRUNDFOS Pumps (Shanghai) Co. Ltd.
10F The Hub, No. 33 Suhong Road
Minhang District
Shanghai 201106 PRC
Tel.: +86 21 612 252 22
Fax: +86 21 612 253 33

Colombia

GRUNDFOS Colombia S.A.S.
Km 1.5 via Siberia-Cota Conj. Potrero
Chico,
Parque Empresarial Arcos de Cota Bod.
1A.
Cota, Cundinamarca
Tel.: +57(1)-2913444
Fax: +57(1)-8764586

Croatia

GRUNDFOS CROATIA d.o.o.
Buzinski prilaz 38, Buzin
HR-10010 Zagreb
Tel.: +385 1 6595 400
Fax: +385 1 6595 499
www.hr.grundfos.com

Czech Republic

GRUNDFOS Sales Czechia and Slovakia
s.r.o.
Čajkovského 21
779 00 Olomouc
Tel.: +420-585-716 111

Denmark

GRUNDFOS DK A/S
Martin Bachs Vej 3
DK-8850 Bjerringbro
Tel.: +45-87 50 50 50
Fax: +45-87 50 51 51
E-mail: info_GDK@grundfos.com
www.grundfos.com/DK

Estonia

GRUNDFOS Pumps Eesti OÜ
Peterburi tee 92G
11415 Tallinn
Tel.: + 372 606 1690
Fax: + 372 606 1691

Finland

OY GRUNDFOS Pumput AB
Trukkikuja 1
FI-01360 Vantaa
Tel.: +358-(0) 207 889 500

France

Pompes GRUNDFOS Distribution S.A.
Parc d'Activités de Chesnes
57, rue de Malacombe
F-38290 St. Quentin Fallavier (Lyon)
Tel.: +33-4 74 82 15 15
Fax: +33-4 74 94 10 51

Germany

GRUNDFOS GMBH
Schlüterstr. 33
40699 Erkrath
Tel.: +49-(0) 211 929 69-0
Fax: +49-(0) 211 929 69-3799
E-mail: infoservice@grundfos.de
Service in Deutschland:
kundendienst@grundfos.de

Greece

GRUNDFOS Hellas A.E.B.E.
20th km. Athinon-Markopoulou Av.
P.O. Box 71
GR-19002 Peania
Tel.: +0030-210-66 83 400
Fax: +0030-210-66 46 273

Hong Kong

GRUNDFOS Pumps (Hong Kong) Ltd.
Unit 1, Ground floor, Siu Wai industrial
Centre
29-33 Wing Hong Street & 68 King Lam
Street, Cheung Sha Wan
Kowloon
Tel.: +852-27861706 / 27861741
Fax: +852-27858664

Hungary

GRUNDFOS Hungária Kft.
Tópark u. 8
H-2045 Törökbalint
Tel.: +36-23 511 111
Fax: +36-23 511 111

India

GRUNDFOS Pumps India Private Limited
118 Old Mahabalipuram Road
Thoraiakkam
Chennai 600 097
Tel.: +91-44 2496 6800

Indonesia

PT GRUNDFOS Pompa
Graha Intirub Lt. 2 & 3
Jln. Cililitan Besar No.454. Makasar,
Jakarta Timur
ID-Jakarta 13650
Tel.: +62 21-469-51900
Fax: +62 21-460 6910 / 460 6901

Ireland

GRUNDFOS (Ireland) Ltd.
Unit A, Merrywell Business Park
Ballymount Road Lower
Dublin 12
Tel.: +353-1-4089 800
Fax: +353-1-4089 830

Italy

GRUNDFOS Pompe Italia S.r.l.
Via Gran Sasso 4
I-20060 Truccazzano (Milano)
Tel.: +39-02-95838112
Fax: +39-02-95309290 / 95838461

Japan

GRUNDFOS Pumps K.K.
1-2-3, Shin-Miyakoda, Kita-ku
Hamamatsu
431-2103 Japan
Tel.: +81 53 428 4760
Fax: +81 53 428 5005

Korea

GRUNDFOS Pumps Korea Ltd.
6th Floor, Aju Building 679-5
Yeoksam-dong, Kangnam-ku, 135-916
Seoul, Korea
Tel.: +82-2-5317 600
Fax: +82-2-5633 725

Latvia

SIA GRUNDFOS Pumps Latvia
 Deglava biznesa centrs
 Augusta Deglava ielā 60
 LV-1035, Rīga,
 Tel.: + 371 714 9640, 7 149 641
 Fax: + 371 914 9646

Lithuania

GRUNDFOS Pumps UAB
 Smolensko g. 6
 LT-03201 Vilnius
 Tel.: + 370 52 395 430
 Fax: + 370 52 395 431

Malaysia

GRUNDFOS Pumps Sdn. Bhd.
 7 Jalan Peguam U1/25
 Glenmarie Industrial Park
 40150 Shah Alam, Selangor
 Tel.: +60-3-5569 2922
 Fax: +60-3-5569 2866

Mexico

Bombas GRUNDFOS de México
 S.A. de C.V.
 Boulevard TLC No. 15
 Parque industrial Stiva Aeropuerto
 Apodaca, N.L. 66600
 Tel.: +52-81-8144 4000
 Fax: +52-81-8144 4010

Netherlands

GRUNDFOS Netherlands
 Veluwezoom 35
 1326 AE Almere
 Postbus 22015
 1302 CA ALMERE
 Tel.: +31-88-478 6336
 Fax: +31-88-478 6332
 E-mail: info_gnl@grundfos.com

New Zealand

GRUNDFOS Pumps NZ Ltd.
 17 Beatrice Tinsley Crescent
 North Harbour Industrial Estate
 Albany, Auckland
 Tel.: +64-9-415 3240
 Fax: +64-9-415 3250

Norway

GRUNDFOS Pumper A/S
 Strømsveien 344
 Postboks 235, Leirdal
 N-1011 Oslo
 Tel.: +47-22 90 47 00
 Fax: +47-22 32 21 50

Poland

GRUNDFOS Pompy Sp. z o.o.
 ul. Klonowa 23
 Baranowo k. Poznania
 PL-62-081 Przeźmierowo
 Tel.: (+48-61) 650 13 00
 Fax: (+48-61) 650 13 50

Portugal

Bombas GRUNDFOS Portugal, S.A.
 Rua Calvet de Magalhães, 241
 Apartado 1079
 P-2770-153 Paço de Arcos
 Tel.: +351-21-440 76 00
 Fax: +351-21-440 76 90

Romania

GRUNDFOS Pompe România SRL
 S-PARK BUSINESS CENTER, Clădirea
 A2, etaj 2
 Str. Tipografilor, Nr. 11-15, Sector 1, Cod
 013714
 Bucuresti, Romania
 Tel.: 004 021 2004 100
 E-mail: romania@grundfos.ro

Russia

ООО Грундфос Россия
 ул. Школьная, 39-41
 Москва, RU-109544, Russia
 Тел. (+7) 495 564-88-00 (495) 737-30-00
 Факс (+7) 495 564 8811
 E-mail grundfos.moscow@grundfos.com

Serbia

Grundfos Srbija d.o.o.
 Omladinskih brigada 90b
 11070 Novi Beograd
 Tel.: +381 11 2258 740
 Fax: +381 11 2281 769
 www.rs.grundfos.com

Singapore

GRUNDFOS (Singapore) Pte. Ltd.
 25 Jalan Tukang
 Singapore 619264
 Tel.: +65-6681 9688
 Fax: +65-6681 9689

Slovakia

GRUNDFOS s.r.o.
 Prievozská 4D 821 09 BRATISLAVA
 Tel.: +421 2 5020 1426
 sk.grundfos.com

Slovenia

GRUNDFOS LJUBLJANA, d.o.o.
 Leskoškova 9e, 1122 Ljubljana
 Tel.: +386 (0) 1 568 06 10
 Fax: +386 (0) 1 568 06 19
 E-mail: tehnika-si@grundfos.com

South Africa

GRUNDFOS (PTY) LTD
 16 Lascelles Drive, Meadowbrook Estate
 1609 Germiston, Johannesburg
 Tel.: (+27) 10 248 6000
 Fax: (+27) 10 248 6002
 E-mail: lgradidge@grundfos.com

Spain

Bombas GRUNDFOS España S.A.
 Camino de la Fuentecilla, s/n
 E-28110 Algete (Madrid)
 Tel.: +34-91-848 8800
 Fax: +34-91-628 0465

Sweden

GRUNDFOS AB
 Box 333 (Lunnagårdsgatan 6)
 431 24 Mölndal
 Tel.: +46 31 332 23 000
 Fax: +46 31 331 94 60

Switzerland

GRUNDFOS Pumpen AG
 Bruggacherstrasse 10
 CH-8117 Fällanden/ZH
 Tel.: +41-44-806 8111
 Fax: +41-44-806 8115

Taiwan

GRUNDFOS Pumps (Taiwan) Ltd.
 7 Floor, 219 Min-Chuan Road
 Taichung, Taiwan, R.O.C.
 Tel.: +886-4-2305 0868
 Fax: +886-4-2305 0878

Thailand

GRUNDFOS (Thailand) Ltd.
 92 Chaloeam Phrakiat Rama 9 Road
 Dokmai, Pravej, Bangkok 10250
 Tel.: +66-2-725 8999
 Fax: +66-2-725 8998

Turkey

GRUNDFOS POMPA San. ve Tic. Ltd.
 Sti.
 Gebze Organize Sanayi Bölgesi
 Ihsan dede Caddesi
 2. yol 200. Sokak No, 204
 41490 Gebze/ Kocaeli
 Tel.: +90 - 262-679 7979
 Fax: +90 - 262-679 7905
 E-mail: satis@grundfos.com

Ukraine

Бізнес Центр Європа
 Столичне шосе, 103
 м. Київ, 03131, Україна
 Tel.: (+38 044) 237 04 00
 Fax: (+38 044) 237 04 01
 E-mail: ukraine@grundfos.com

United Arab Emirates

GRUNDFOS Gulf Distribution
 P.O. Box 16768
 Jebel Ali Free Zone, Dubai
 Tel.: +971 4 8815 166
 Fax: +971 4 8815 136

United Kingdom

GRUNDFOS Pumps Ltd.
 Grovebury Road
 Leighton Buzzard/Beds. LU7 4TL
 Tel.: +44-1525-850000
 Fax: +44-1525-850011

U.S.A.

GRUNDFOS Water Utility Head Quarters
 Brookshire, Texas 77423 USA

Uzbekistan

Grundfos Tashkent, Uzbekistan
 The Representative Office of Grundfos
 Kazakhstan in Uzbekistan
 38a, Oybek street, Tashkent
 Tel.: (+998) 71 150 3290 / 71 150 3291
 Fax: (+998) 71 150 3292

Revision Info

Last revised on 09-09-2020

98142266 03.2021

ECM: 1300795
